Taylor Valve Technology®

R1 SERIES CONTROL CHOKE



R1 SERIES CONTROL VALVES



he R1 Series Control Valve features several unique design characteristics that minimize wear and maximize service life.

The nozzle and external sleeve trim is designed to contain turbulence and wear by managing the flow into the nozzle and centralizing it into bore causing the flow streams to impinge on each other. The valve body and outlet are protected from wear because the energy conversion as a result of the pressure drop is concentrated in the trim cavity before flow enters the outlet. This eliminates the typical wear problems in the valve outlet.

The sleeve design greatly reduces the breakway and closing thrust requirements to lift the sleeve on and off seat as well as during stem travel making the control stable and precise yielding better accuracy and repeatability.

- Accurate Control Multi-Orifice Nozzle design provides precise control over a wide range of flows.
- **Bolted Bonnet** A bolted bonnet prevents corrosion, cross-threading and galling of large threaded connections. The design allows for simple assembly and disassembly.
- Extended Mean Time Between Service Robust design, application of hardened materials, and efficient flow geometry results in maximum production potential and minimum service requirements.
- Easy Maintenance All Control Choke Valves are designed with special actuator mounting systems so the choke can be maintained without disassembly of the actuator and components or instrument connections.
- High Turndown Ratio Clean flow geometry, high capacity and accurate control means the valve is suitable for both start-up and end-of field-life-process scenarios. In short, our control choke valves offer a one-valve solution for the full process life.
- Optional Features Control Valves can have trims and actuators custom designed for specific requirements. Such as special noise reduction trims, reduced port and maximum orifice trims for very high pressure or minimum pressure loss for a declining field.

Applications:

- Well Site Automated and Manual Application
- Water Injection Control Valve
- CO2 Injection Control Valve
- High Pressure Drop Applications
- Gas Lift Injection Control


Taylor Valve Technology®

WWW.TAYLORVALVE.COM



R1 CONTROL VALVE SERIES

Dynamic Energy Conversion



When the valve is open and flow enters through the inlet of the valve into the protective cage, it is circulated around the annulus created by the cage, nozzle and sleeve assembly. The symmetry of the ports in the nozzle cause the high velocity fluid streams created by the pressure drop to collide into each other in the center of the trim. The impact of the streams converts the energy and protects

the downstream components from damage.




Multi-Orifice Nozzle Technology


Control Element

The R1 Series valve features several unique design characteristics that minimize wear and maximize service life.


The nozzle and external sleeve trim is designed to contain turbulence and wear by managing the flow into the nozzle and centralizing it into bore causing the flow streams to impinge on each other. The valve body and outlet are protected from wear because the energy conversion as a result of the pressure drop is concentrated in the trim cavity before flow enters the outlet. This eliminates the typical wear problems in the valve outlet.







CLOSED POSITION OPEN AND THROTTLING The Trim configuration has been field-tested and proven to deliver superior wear resistance and performance. The trim controls high velocity fluid during pressure reduction by directing the flow to the center of the flow nozzle. The Erosive Energy is contained within the expendable trim components away from the valve wall which is additionally protected by a replaceable sleeve, reducing the potential for release of fluids to the environment. The seat and Tri-seating surfaces on the sleeve are separate from the controlling surfaces and out of the flow path to maintain an ANSI class V shut off.







R1 Cutaway View

R1 Control Choke

Cv = 12 (Standard), 6, 3 Bean Size = 47/64ths Stroke Length = 1" Stem Diameter = 0.625" MAWP = 5,000 PSIG





ITEM	DESCRIPTION	QTY
1	O-RING 2-029	1
2	O-RING 2-225	2
3	O-RING 2-222	1
4	O-RING 2-032	1
5	THUMB SCREW	1
6	FLAT WASHER	4
7	NEEDLE ROLLER BEARING	2
8	HEX BOLT	6
9**	HEX BOLT	4
10*	SET SCREW	1
11	HEX NUT (Lock Nut)	1
12	NOZZLE	1
13	SEAT	1
14	CAGE	1
15	EXTERNAL SLEEVE ASSEMBLY	1
16	BONNET	1
17	BODY/FLANGE WELDMENT	1
18	STEM	1
19	WASHER	1
20	SNAP RING	1
21	U-CUP SEALS	2
22**	ANTI-ROTATIONAL DEVICE	1
23**	STEM ADAPTER/DRIVE PLATE	1
24*	PIPE PLUG	1
25**	TURN HANDLE	1

*Item not visible in sectioned view

**Parts not included on actuator



The information contained in these drawings is the sole property of Taylor Valve Technology Inc. and any reproduction in part or whole without the written permission of Taylor Valve Technology Inc. is prohibited.


NOTE: Taylor Valve reserves the right to change product designs and specifications without notice.




R1 Dimensions and Weights

www.taylorvalve.com

1" BODY STANDARD DIMENSIONS AND WEIGHTS						2" BODY STANDARD DIMENSIONS AND WEIGHTS					
CONNECTIONS		DIM. END-to-END IN. (MM.) +/10		WEIGHT		CONNECTIONS		DIM. END-to-END IN. (MM.) +/10		WEIGHT	
INLET	OUTLET	А	В	LB.	KG.	INLET	OUTLET	А	В	LB.	K
1" FNPT	1" FNPT	5.53 (140)	2.80 (71)	23	10.44	2" FNPT	2" FNPT	5.58 (142)	2.74 (70)	22	9.9
1" FNPT	1" FNPT	5.58 (142)	2.74 (70)	23	10.44	2" BUTT WELD	2" BUTT WELD	5.58 (142)	2.74 (70)	22	9.9
1" BUTT WELD	1" BUTT WELD	5.58 (142)	2.74 (70)	22	9.99	2" 150 RFJ	2" 150 RFJ	8.17 (208)	5.33 (135)	33	14.
1" 150 RFJ	1" 150 RFJ	7.86 (200)	5.02 (128)	28	12.71	2" 150 RTJ	2" 150 RTJ	8.36 (212)	5.52 (140)	33	14.
1" 150 RTJ	1" 150 RTJ	8.05 (204)	5.21 (132)	28	12.71	2" 300 RFF	2" 300 RFF	8.42 (214)	5.58 (142)	39	17.
1" 300 RFF	1" 300 RFF	8.11 (206)	5.27 (134)	30	13.62	2" 300 RTJ	2" 300 RTJ	8.67 (220)	5.83 (148)	39	17.
1" 300 RTJ	1" 300 RTJ	8.30 (211)	5.46 (139)	30	13.62	2" 600 RFF	2" 600 RFF	8.80 (224)	5.96 (151)	45	20.
1" 600 RFF	1" 600 RFF	8.36 (212)	5.52 (140)	30	13.62	2" 600 RTJ	2" 600 RTJ	8.86 (225)	6.02 (153)	45	20
1" 600 RTJ	1" 600 RTJ	8.36 (212)	5.52 (140)	30	13.62	2" 900/1500 RFF	2" 900/1500 RFF	9.92 (252)	7.08 (180)	72	32
" 900/1500 RFF	1" 900/1500 RFF	8.80 (224)	5.96 (151)	40	18.16	2" 900/1500 RTJ	2" 900/1500 RTJ	9.98 (253)	7.14 (181)	72	32
" 900/1500 RTJ	1" 900/1500 RTJ	8.80 (224)	5.96 (151)	40	18.16	2" 2500 RFF	2" 2500 RFF	10.92 (277)	8.08 (205)	106	48
1" 2500 RFF	1" 2500 RFF	9.42 (239)	6.58 (167)	46	20.88	2" 2500 RTJ	2" 2500 RTJ	10.98 (279)	8.14 (207)	106	48
1" 2500 RTJ	1" 2500 RTJ	9.42 (239)	6.58 (167)	46	20.88	2-1/16" 3000 API	2-1/16" 3000 API	9.98 (253)	7.14 (181)	74	33
						2-1/16" 5000 API	2-1/16" 5000 API	9.98 (253)	7.14 (181)	76	34
						2-9/16" 3000 API	2-9/16" 3000 API	10.11 (257)	7.27 (185)	94	42
						2-9/16" 5000 API	2-9/16" 5000 API	10.11 (257)	7.27 (185)	96	43





*For more options, contact Taylor Valve.

Taylor Valve Technology

Oklahoma City, Oklahoma 73128

8300 S.W. 8th Street

40 6" 300

87 1.5" 1500

TEL 405.787.0145

FAX 800.805.3401 WEB www.taylorvalve.com EMAIL info@taylorvalve.com